


ATO

WHAT IS IN THE BOX?

- 9 x Metal Threaded Rods
- 10 x Wooden Bodies
- 100 x Screws (10 Spare)

STEP 1

Slide the following bodies from the bottom starting with **Body F** with their screws.
(Use Figure 1 as reference)



STEP 2

Slide the remaining bodies from the top starting with **Body E** and ending with **Body A** as shown.





Figure 1

