


**Mohh**



[www.mohh.com](http://www.mohh.com)  
+91 78400 03330

Name  
Code  
Dimensions(mm)  
Range

Trisley Console  
M-MWC-052  
1200x300x900mm  
Consoles


# Trisley Console

## WHAT IS IN THE BOX?

1 x Wooden top (1200x300mm)  
2 x Metal Leg frames with planters  
20 x screws (4 spare)


### STEP 1

Place the wooden top on the floor as shown, preferably on a soft surface or rug.




### STEP 2

Insert the leg frame in the slot.




### STEP 3

Screw the leg member to the wooden top.



### STEP 4

Similarly fix the other leg member just remember to fix it in opposite direction as shown.



### STEP 5

Turn the console in upright position and prop it in your fashion!

